

WUFI®

Guideline for the Calculation of Pitched Roofs

Date: March 2026

Content


Introduction.....	<u>slide 3</u>
Notes on the Input	
– Component Assembly.....	<u>slide 4</u>
– Infiltration Source.....	<u>slide 5</u>
– Initial Conditions.....	<u>slide 7</u>
– Boundary Conditions (exterior).....	<u>slide 8</u>
– Boundary Conditions (interior).....	<u>slide 16</u>
– Control.....	<u>slide 17</u>
Notes on the Evaluation	
– Mineral Wool Insulation.....	<u>slide 18</u>
– Wood Fibre Insulation.....	<u>slide 19</u>
– Wooden Sheathing.....	<u>slide 20</u>
Literature.....	<u>slide 24</u>
Examples: Pitched Roof with Mineral Wool and Wooden Sheathing.....	<u>slide 25</u>
– Assembly and Boundary Condition.....	<u>slide 26</u>
– Evaluation Matrix.....	<u>slide 28</u>
– Procedure for Input.....	<u>slide 29</u>
– Procedure for Evaluation.....	<u>slide 39</u>

Introduction

This guideline explains the procedure of the calculation and evaluation of pitched roofs with a vapour retarder applied on the whole interior surface.

In the first step all necessary input data and the evaluation criteria are described.

The procedure from input to evaluation is then explained using an example case.



Component - Assembly

Roof Cladding with Tiles

The ventilated roof cladding is replaced in the simulation by effective transfer parameters, e. g. according to Kölsch [1]. So, this is not modelled for the simulation.

Underlay / Weather Protection Membrane

The underlay / weather protection membrane is also not included in the calculation as a component layer but is considered as an s_d -value in the surface transfer parameters. This leads to practically identical results but speeds up the calculation significantly compared to taking the roofing membrane into account in the component structure.

Underlying Roof Assembly

The underlying layers are to be entered according to the assembly in the cross section of the insulated cavity.

Component - Assembly

Moisture Source – Infiltration

According to EN 15026 [7], the amount of moisture which enters the construction by convection depending on the air tightness of the envelop always needs to be assessed for wooden structures. In the simulation it is considered using the IBP infiltration model.

The moisture source must be placed at the position in the model where the condensation water will form in practice – usually this is below the second airtight layer on the cold side of the component.

For roof constructions we recommend the following settings:

- with wooden sheathing: moisture source in the interior 5 mm of the wooden sheathing
- without wooden sheathing: moisture source in the exterior 5 mm of the insulation layer

Component – Assembly

Moisture Source – Infiltration

The source strength is automatically determined depending on the overpressure due to the building's thermal buoyancy (temperature difference between outside and inside as well as specified air space height), the indoor air humidity and the specified airtightness of the building envelope [3].

For more information on using the infiltration source in WUFI[®], click here: [Guideline for Using the Air Infiltration Source in WUFI[®]](#)

Component – Initial Conditions

Initial Temperature and Moisture:

A constant initial relative humidity of 80 % and an initial temperature of 20 °C is recommended as a default setting.

If increased built-in moisture contents are known, these can be specified separately for the corresponding layer.

Boundary Conditions (exterior) – Climate

Outdoor Climate:

A climate appropriate for the location of the building should be used.

For Germany:

The hygrothermal reference years (HRY), which were created for 11 locations in Germany as part of a research project [5], are useful here. These locations are representative for the respective climate region. For more information, please refer to the *WUFI® Help (F1) → Topic: Hygrothermal Reference Years*

The Holzkirchen location, with 20% reduced radiation, is considered critically representative of German locations up to altitudes of 700 m. This can be considered in the simulation by reducing the absorption coefficient from a to $a \cdot 0.8$. This climate was also used for the exemption of deemed-to-satisfy constructions in DIN 4108-3 [4].

Boundary Conditions (exterior) – Orientation

Orientation

The relevant orientation usually is North where the lowest radiation gains occur. Alternatively, the most unfavourable orientation of the building part can be used for specific projects.

Inclination

The inclination of the roof must be specified according to the planned roof inclination.

Notes on the Input: Surface Transfer Coefficients (exterior)

Boundary Conditions (exterior) – Surface

Heat Transfer

The heat transfer coefficient is set according to the following tables (Kölsch [1]); the long-wave radiation parts of the heat transfer coefficients must be set to 0 W/m²K, as the radiation is calculated explicitly.

Usually „normally ventilated“ can be assumed!

Strong ventilated	$a_{k,e} = 30 \text{ [W/m}^2\text{K]}$
Normal ventilated	$a_{k,e} = 19 \text{ [W/m}^2\text{K]}$
Low ventilated	$a_{k,e} = 13,5 \text{ [W/m}^2\text{K]}$

$a_{k,e}$: convective heat transfer coefficient

Strong ventilated	Eaves open without any ventilation grid etc.	Ridge open with a low flow resistance	
Normal ventilated	Eaves openings with insect protection grid or eave comb	Ridge closed with ridge / arris role	
Low ventilated	Small openings at the eaves	Small openings at the ridge	No counter battens

Boundary Conditions (exterior) – Surface

Vapor Transfer (Additional diffusion resistance)

The underlay / weather protection membrane is considered as s_d -value in the surface transfer parameters, instead of modelling it as a layer.

Underlay membranes with s_d -values of less than 0.1 m are offered on the market. As this value may increase due to dust and deposits, the s_d -value of the underlay membrane should be set at a minimum of 0.1 m in the calculation according to the note in the German Standard DIN 4108-3 [4].

Boundary Conditions (exterior) – Surface

Vapor Transfer (Additional diffusion resistance)

Note for constructions with absorbent underlay materials:

In the case of assemblies with exterior wooden sheathing, an additional s_d -value of 0.01 m must be applied to the external surface to avoid unrealistically high condensation on the substructure caused by the absence of roof tiles in the simulation.

For a more detailed explanation, see [Hygrothermal Simulation of ventilated pitched roofs with effective transfer parameters](#), chapter 8.


Notes on the Input: Surface Transfer Coefficients (exterior)

Boundary Conditions (exterior) – Surface

Radiation: Short-wave absorptivity

The short-wave radiation absorptivity should be selected depending on the colour of the roof tiles (examples below or in right table) and, if necessary, be reduced according to Kölsch [1] (table on next slide).

Red tiles	$a = 0.67 - 0.78$
Grey tiles	$a \sim 0.85$
Dark tiles	$a = 0.9 - 0.94$



Red, high gloss glazed	Brick red	Light red, semi-matt	Light red, matt (weathered)	Natural clay red, matt	Light grey	Black
0.72	0.74	0.75	0.76	0.78	0.85	0.94

Notes on the Input: Surface Transfer Coefficients (exterior)

Boundary Conditions (exterior) – Surface

Radiation: Reduction factors

The middle position can be used to evaluate typical conditions, especially if the coldest position (30 cm distance to the eaves opening) is still in the area of the roof overhang. This reduction can be considered in the reduction factors (drop-down menu).

	Coldest position	Middle position	Warmest position
Strong ventilated	$a_e = a \cdot 0.7$	$a_e = a \cdot 0.9$	$a_e = a$
Normal ventilated	$a_e = a \cdot 0.7$	$a_e = a \cdot 0.9$	$a_e = a$
Low ventilated	$a_e = a \cdot 0.75$	$a_e = a \cdot 0.9$	$a_e = a$

a_e : effective coefficient of absorption

Boundary Conditions (exterior) – Surface

Radiation: Long-wave emissivity

The long-wave radiation emissivity depends on the surface condition of the clay / concrete tiles and varies between 0.82 and 0.91.

Clay tile, high gloss glazed	$\varepsilon \sim 0.82$
Clay tile, matt	$\varepsilon \sim 0.84$
Concrete tile, in general	$\varepsilon = 0.9 - 0.91$

To consider the (night-time) overcooling, the explicit radiation balance must always be switched on for roofs due to its large field of view to the sky.

Rain

The roofing is assumed to be waterproof, so the absorption of rainwater must be switched off.

Note: The setting for the s_d -value in the boundary condition only affects the diffusion behaviour of the surface and not the liquid water absorption.

Boundary Conditions (interior) – Climate / Surface

Indoor Climate:

By default, we recommend to use the indoor climate with medium moisture load + 5% for design purposes according to German Standard DIN 4103-3 [4] and EN 15026 [7].

Alternatively, depending on the use of the building, the indoor climate can also be set with low moisture load (according to EN 15026 [7]) or with normal or high moisture load (according to DIN 4108-3 [4] and EN 15026 [7]). Constant or measured conditions can also be set, for example.

Heat Transfer

The heat transfer coefficient on the interior surface is set to 8 W/m²K in accordance with DIN 4108-3 [4].

Control

Calculation Period:

It is recommended to start the calculation on October 1st, because the component usually moistens up further in the following winter months before drying to the inside possibly starts in spring. This start date is therefore usually an extra stressing of the component.

The calculation time depends on the time the construction needs to reach steady state conditions. Usually, a calculation time of 5 years is sufficient. In the case of diffusion-open building components, the calculation times tend to be shorter, in the case of diffusion-tight building components, the calculation times tend to be longer.


Notes on the Evaluation: Mineral Wool Insulation

Roofs with mineral wool insulation and underlay membrane

These assemblies do not have any moisture-sensitive materials in the standard cross-section (insulated cavity). Below the roofing felt, due to the higher diffusion resistance compared to the insulation, temporarily increased moisture or condensation may occur.


The amount of condensation occurring below the roofing felt is used for result evaluation. For this purpose, the maximum water content in [kg/m³] in the outer area of the mineral wool insulation is evaluated. The guideline "[Assessing the risk of interstitial condensation runoff](#)" presents the condensation water retention capacity (RC) as a practical limit value and describes how to assess the risk of condensation water runoff using hygrothermal simulation.

The assessing method recommended until 2023 for hydrophobic mineral fiber insulation materials has been replaced by new findings and extended to other fiber insulation materials.



Roofs with wood fibre insulation and underlay membrane

For assemblies with wood fibre insulation between the rafters, an evaluation of the wood moisture in the wood fibre insulation is performed.




For this purpose, the wood moisture content is evaluated in [% by mass] in the outer centimeter of the wood-fiber insulation in the settled state. The settled stage has reached if the course of the water content does not change between the years any longer.

For evaluation purposes, the general limit value of 18 % by mass from DIN 68800 [2] can be used, which may be exceeded by a maximum of 20 % by mass for up to three months a year. Alternatively, the manufacturer can guarantee the maximum moisture content for which his product can be used.

Roofs with insulation and wooden sheathing

For assemblies with exterior wooden sheathing, the insulation between the rafters (mineral wool or wood fibre) is evaluated according to [slide 18+19](#).



For the evaluation of the wooden sheathing, the course of the wood moisture content in [% by mass] in the wooden sheathing in the settled state is used. The value of 20 % by mass for wood and 18 % by mass for wood-based materials specified in DIN 68800 [2] is recommended as the limit value. If this limits are kept, no further evaluation is necessary.

If the wood moisture exceeds the limit value according to DIN 68800 [2], an evaluation according to the WTA Guideline 6-8 [8] can also be carried out for solid wood. This allows a more precise evaluation considering the temperature and humidity conditions.


Roofs with insulation and wooden sheathing

Evaluation according to DIN 68800 [2]

Critical moisture conditions regarding damage to the wood can occur, if the moisture content limits of 20 % by mass for wood and 18 % by mass for wood-based materials are exceeded over a long period.

However, this limit value includes high safety margins and, in contrast to the WTA guideline 6-8 [8], no specifications are made for the evaluation area. In the case of thin wooden sheathings, the entire section of the sheathing shall be evaluated, otherwise the most critical 1 cm thick section should be used in accordance with the WTA evaluation.

If the wood moisture remains below the limit values (see above), no further evaluation is necessary.




Roofs with insulation and wooden sheathing

Evaluation according to WTA Guideline 6-8 [8]

If the limit value for wood of 20 % by mass according to DIN 68800 [2] is exceeded, also an evaluation according to the WTA 6-8 [8] can be carried out. Here, the evaluation of wood structures is carried out based on temperature-dependent limit values for the relative pore air humidity in a 1 cm thick layer at the critical position of the wood. This allows a more accurate and realistic evaluation.


Please note: This evaluation cannot be used for wood-based materials, as other limit values for rotting processes may apply here.




Notes on the Evaluation: Wooden Sheathing

Roofs with insulation and wooden sheathing

Limit curve for wood decay depending on temperature (x-axis) and relative humidity (y-axis) according to WTA 6-8 [8].




At conditions below the red limit line, wood decay is not possible in solid wood.



- [1] Kölsch, Ph.: Hygrothermal simulation of ventilated pitched roofs with effective transfer parameters. 01/2017. ([Guideline for the simulation of ventilated pitched roofs with effective transfer parameters](#))
- [2] DIN 68800-2: Holzschutz – Teil 2: Vorbeugende bauliche Maßnahmen im Hochbau. Beuth Verlag, February 2022.
- [3] Zirkelbach, D.; Künzel, H.M.; Schafaczek, B. und Borsch-Laaks, R.: Dampfkonvektion wird berechenbar – Instationäres Modell zur Berücksichtigung von konvektivem Feuchteintrag bei der Simulation von Leichtbaukonstruktionen. Proceedings 30. AIVC Conference, Berlin 2009.
- [4] DIN 4108-3: Klimabedingter Feuchteschutz, Anforderungen, Berechnungsverfahren und Hinweise für Planung und Ausführung. Beuth Verlag, March 2024.
- [5] Research Report: Energieoptimiertes Bauen: Klima- und Oberflächenübergangsbedingungen für die hygrothermische Bauteilsimulation. IBP-Bericht HTB-021/2016. Durchgeführt im Auftrag vom Projektträger Jülich (PTJ UMW). July 2016.
- [6] WTA-Guideline 6-2/E: Simulation of heat and moisture transfer. October 2025.
- [7] EN 15026: Hygrothermal performance of building components and building elements – Assessment of moisture transfer by numerical simulation. Beuth Verlag, December 2023.
- [8] WTA-Guideline 6-8: Feuchtetechnische Bewertung von Holzbauteilen – Vereinfachte Nachweise und Simulationen. August 2016.

Example: Pitched Roof with Mineral Wool and Wooden Sheathing

Based on the example of a pitched roof with mineral wool insulation and wooden sheathing, the procedure for the input and the evaluation is described.



- 1 Roofing and Battens
- 2 Weather Protection Membrane
- 3 Wooden Sheathing
- 4 Insulation
- 5 Vapour Retarder
- 6 Installation Layer
- 7 Gypsum Board

Example: Assembly

Assembly (from outside to inside):

- Red Concrete Tiles
- Weather Protection Membrane ($s_d = 0.1$ m)
- Wooden Sheathing (Softwood) 0.025 m
- Mineral Wool (heat cond.: 0.04 W/mK) 0.24 m
- Moisture-Variable Vapour Retarder (Intello Plus) 0.001 m
- Air Layer 0.02 m
- Gypsum Board 0.0125 m

Example: Boundary Conditions

Boundary Conditions:

- Pitched roof (30° to the North)
- Red concrete tiles
($a = 0.67$; $\varepsilon = 0.9$)
- Normal ventilated roof (middle position)
- Outdoor climate: Holzkirchen
- Indoor climate: medium moisture load + 5 %
- Air tightness of the envelope: $q_{50} = 3 \text{ m}^3/\text{m}^2\text{h}$
- Stack Height: 5 m

Example: Evaluation Matrix

Evaluation Matrix:

The following matrix shows the evaluation criteria relevant to this design.

	Criteria
1) Numerics	No or only small differences in balances (especially in the case of convergence failures)?
	Consistent, periodic course of total water content?
2) Evaluation parameters	Total water content reach dynamic equilibrium or decreases?
	Risk of wood decay in the wooden sheathing? (limit values according to DIN 68800 or WTA 6-8)
	Amount of condensation in the insulation layer?

Example: Component Assembly

Input: Component - Assembly

The screenshot shows the WUFI Pro 7.1 software interface for configuring a roof assembly. The 'Gypsum Board' layer thickness is highlighted with a green box and set to 0.0125 m. The assembly includes layers for Softwood (0.025 m), Mineral Wool (0.24 m), Air Layer (0.02 m), and Gypsum Board (0.0125 m). The performance metrics are as follows:

Geometry Properties	Total Thermal Performance	
Total Thickness [m]: 0.299	R-Value (dry) [m ² K/W]: 6.49	U-Value (dry) [W/m ² K]: 0.15
Number of Layers: 5	R-Value (at 80% RH) [m ² K/W]: 6.45	U-Value (at 80% RH) [W/m ² K]: 0.151

Enter roof assembly without roofing tiles and weather protection membrane
Adjust layer thicknesses if necessary

Example: Infiltration Source

Input: Component - Assembly

Infiltration source in the wooden sheathing according to EN 15026

WUFI Pro 7.1

Project Run Outputs Database Result Analysis Help

Project

- Case: 1 Pitched Roof
 - Component
 - Assembly
 - Initial Conditions
 - Boundary Conditions (exterior)
 - Boundary Conditions (interior)
 - Control
 - Results

Layer: Softwood (formwork, thin layers) Thickness [m]: 0.025

Exterior (Left Side) Interior (Right Side)

Softwood... 0.025 m Mineral Wool (heat cond.: 0,04 W/mK) 0.24 m Air Lay... Gyp... 0.02 m 0.0...

+ New Layer Duplicate Delete Materials Material Data Constructions Save

Grid and Sources Original Size 100%

Select Infiltration source

- Infiltration Source
- Rain Source
- Heat Source
- Moisture Source
- Air Change Source

Grid Setting Automatic (II) 200 Elements Geometry Setting cartesian

Geometry Total Thermal Performance

Total Thickness [m]: 0.299	R-Value (dry) [m ² K/W]: 6.49	U-Value (dry) [W/m ² K]: 0.15
Number of Layers: 5	R-Value (at 80% RH) [m ² K/W]: 6.45	U-Value (at 80% RH) [W/m ² K]: 0.151

Example: Infiltration Source

Input: Component - Assembly

Moisture Source in the interior 5 mm of the wooden sheathing.

Hygrothermal Sources

Infiltration Source

Name Infiltration 1

Spread Area

Grid Element

Area right-fixed

Whole Layer

Thickness [m] 0.005

Source Type

Transient from File

Fraction of incident Driving Rain

Air Infiltration model IBP

Constant Monthly Moisture Load

Source Term Cut-Off [kg/m³]

No Cut-Off

Cut-Off at Max. Water Content

Cut-Off at Free Water Saturation

User-Defined

Envelope Infiltration q₅₀ [m³/m²h]

3 Air Tightness Class B (DIN 4108, tested <= 3 m³/m²h)

Stack Height [m] 5


Mechanical Ventilation Overpressure [Pa] 0

Delete source OK Cancel Help

Adjust Infiltration Source

Example: Initial Conditions

Input: Component – Initial Conditions




The screenshot displays the WUFI Pro 7.1 software interface. The left sidebar shows the project structure: Project > Case: 1 Pitched Roof > Component > Assembly > Initial Conditions. The main window shows the 'Initial Conditions' settings for the selected component. The 'Initial Temperature' is set to 20°C, and the 'Initial Moisture' is set to 0.8. Below these settings is a table titled 'Initial Conditions in Different Layers'.

No.	Material Layer	Thickness [m]	Temperature [°C]	Rel. Humidity [-]	Water Content [kg/m ³]	Typical Built-In ... [kg/m ³]
1	Softwood (formwork, thin layers)	0.025	20	0.8	60	60
2	Mineral Wool (heat cond.: 0,04 W/mK)	0.24	20	0.8	1.787	1.787
3	INTELLO PLUS (ETA)	0.001	20	0.8	6.7	6.7
4	Air Layer 20 mm; without additional moisture capacity	0.02	20	0.8	0.0136	0.01
5	Gypsum Board	0.0125	20	0.8	6.3	6.3

No changes required

Example: Outdoor Climate

Input: Boundary Conditions (exterior) – Climate



Example: Orientation / Inclination

Input: Boundary Conditions (exterior) – Orientation

The screenshot displays the WUFI Pro 7.1 software interface. The left sidebar shows a project tree with 'Case: 1 Pitched Roof' selected, and 'Orientation' highlighted under 'Boundary Conditions (exterior)'. The main window is divided into three panels:

- Orientation:** A compass rose showing cardinal directions (N, S, E, W) and intercardinal directions (NE, SE, SW, NW). A red arrow points towards the North. A dropdown menu below the compass is set to 'North'.
- Inclination:** A diagram of a pitched roof with a sun icon above it. The angle of inclination is labeled as 30°. Below the diagram, there are two input fields: 'Inclination [°]' with a value of 30 and 'Inclination [%]' with a value of 57.74.
- Building Height / Driving Rain Coefficients:** Two radio buttons are present: 'Rain load calculation according to WUFI model' (selected) and 'Rain load calculation according to ASHRAE Standard 160'. Below these are two input fields: 'R1 [-]' with a value of 1 and 'R2 [s/m]' with a value of 0. A note below reads: 'Note: Rain Load = Rain * (R1 + R2 * Wind Velocity)'.

A green callout box in the bottom right corner of the software window contains the text: **Adjust orientation and inclination**.

Example: Surface Transfer Coefficients (exterior)

Input: Boundary Conditions (exterior) – Surface

WUFI Pro 7.1

Project Run Outputs Database Result Analysis Help

Project

- Case: 1 Pitched Roof
 - Component
 - Assembly
 - Initial Conditions
 - Boundary Conditions (exterior)
 - Climate
 - Orientation
 - Surface
 - Boundary Conditions (interior)
 - Control
 - Results

Heat Transfer

Heat Transfer Coefficient [W/m²K] 19 Pitched roof, normal ventilated

long-wave radiation parts Heat Transfer Coefficient [W/... 0

wind-dependent

Wind-dependence formula

Vapor Transfer

Additional diffusion resistance (e.g. coating), sd-Value [m] 0,1 User-Defined

Note: This setting does not affect rain absorption.

Radiation

Short-wave absorptivity, e.g. solar radiation [-] 0,67 Tiles, red

Radiative overcooling Note: Explicit Radiation Balance, includes radiative cooling due to long-wave emission.

Long-wave emissivity, e.g. nighttime radiative cooling [-] 0,9

Additional radiation parameters

Reduction factors

for absorptivity [-] 0,9 Pitched roof, ventilated, middle position

for emissivity [-] 1,0

Rain

Simulation takes rain into account

Rain parameters

Adjust surface transfer coefficients!

Heat transfer coefficient
(from list: pitched roof,
normally ventilated)

Weather protection
membrane ($s_d = 0,1$ m)

Absorptivity
(from list: Tiles, rot)


Consider Radiative
overcooling

Reduction factors
(from list: Pitched roof,
ventilated, middle position)

No rainwater absorption


Example: Indoor Climate

Input: Boundary Conditions (interior) – Climate



Example: Surface Transfer Coefficients (interior)


Input: Boundary Conditions (interior) – Surface



The screenshot displays the WUFI Pro 7.1 software interface. The left sidebar shows a project tree with 'Case: 1 Pitched Roof' expanded, and 'Boundary Conditions (interior)' > 'Surface' selected. The main window shows the 'Heat Transfer' and 'Vapor Transfer' settings for the selected surface. The 'Heat Transfer' section has a checked box for 'Apply list selection from exterior surface', a text input field containing '8', and a dropdown menu showing 'Pitched roof, normal ventilated (Interior Surface)'. The 'Vapor Transfer' section has a text input field containing '....' and a dropdown menu showing 'No coating'. A green callout box in the bottom right corner of the software window contains the text 'No changes required'.

Example: Calculation Period and Numerics

Input: Control



The screenshot displays the WUFI Pro 7.1 software interface. The left sidebar shows a project tree with 'Control' selected. The main panel is divided into three sections: 'Period of Calculation', 'Adaptive Time Step Control', and 'Numerics'. In the 'Period of Calculation' section, the 'Calculation Period' is set to 5.0 years, which is highlighted with a green box. A green callout box at the bottom right of the interface contains the text 'Adjust calculation period if necessary'.

WUFI Pro 7.1

Project Run Outputs Database Result Analysis Help

Project

- Case: 1 Pitched Roof
 - Component
 - Assembly
 - Initial Conditions
 - Boundary Conditions (exterior)
 - Climate
 - Orientation
 - Surface
 - Boundary Conditions (interior)
 - Climate
 - Surface
 - Control**
 - Results

Period of Calculation ?

Start of Calculation Oct 1, 2026

Calculation Period 5.0 years

Define profiles

Adaptive Time Step Control ?

Enable

Adjust options

Numerics ?

Mode of Calculation


Hygrothermal Special Options

Numerical Expert Settings

Adjust calculation period if necessary

Example: Evaluation – Check for numerical quality

Evaluation:



The screenshot displays the WUFI Pro 7.1 software interface. The left sidebar shows the project structure for 'Case: 1 Pitched Roof', with 'Results' selected. The main window shows the 'Status of Calculation' and 'Check for numerical quality' sections. The 'Check for numerical quality' section contains a table with the following data:

Check for numerical quality			
No. of Convergence Failures			0
Sum of diffusive fluxes (left/right)	[kg/m ²]	-2.248	-1.115
Sum of capillary fluxes (left/right)	[kg/m ²]	0.000	0.000
Balance (mass vs. sum of surface-fluxes)	[kg/m ²]	-0.441	-0.443

Below this table, there are two sections for 'Water Content [kg/m²]':


	Start	End	Min.	Max.
Total Water Content	2.015	1.572	1.196	2.290

Layer/Material	Start	End	Min.	Max.
Softwood (formwork, thin layers)	60.000	54.498	36.934	85.609
Mineral Wool (heat cond.: 0,04 W/mK)	1.787	0.656	0.361	1.787
INTELLO PLUS (ETA)	6.700	1.773	0.682	6.700
Air Layer 20 mm; without additional moisture cap	0.014	9.3E-3	6.4E-3	0.014
Gypsum Board	6.300	4.023	2.628	6.300



Example: Evaluation – Total Water Content


Evaluation: Total Water Content



Example: Evaluation – Wooden Sheathing

Evaluation:

Moisture Content in the Wooden Sheathing




Example: Evaluation – Amount of Condensation

Evaluation:

Amount of condensation in the mineral wool insulation

→ Evaluation of the water content in the outer centimetre of the insulation



Note:

Further information, including information on inclination-dependent limit values, can be found in the guideline:

[Guideline for assessing the risk of interstitial condensation runoff](#)

Example: Evaluation – Amount of Condensation

Evaluation: Amount of condensation in the mineral wool insulation

→ Evaluation of the water content in the outer centimetre of the insulation

1. Selection range of 1 cm

2. Select outer centimetre of the insulation


3. Enter „OK“

Options	Values
Result quantity	Water content in kg/m ³
Title	Water Content
Series name	Water Content
Color	
X-Axis label	Time
Y-Axis label	Water content [kg/m ³]
Start Date	10/1/2026 12:00 AM

Example: Evaluation – Amount of Condensation

Evaluation: Amount of condensation in the mineral wool insulation

→ Evaluation of the water content in the outer centimetre of the insulation



Maximum water content = 4.0 kg/m^3

$4.0 \text{ kg/m}^3 * 0.01 \text{ m (layer thickness)} = 0.040 \text{ kg/m}^2 = 40 \text{ g/m}^2$

→ Condensation remains below the minimum limit value of 100 g/m^2
($\hat{=}$ minimum retention capacity)

Example: Evaluation – final Evaluation

Final Evaluation:

	Criteria	Evaluation
1) Numerics	No or only small differences in balances (especially in the case of convergence failures)?	✓
	Consistent, periodic course of total water content?	✓
2) Evaluation parameters	Total water content reach dynamic equilibrium or decreases?	✓
	Risk of wood decay in the wooden sheathing? (limit values according to DIN 68800 or WTA 6-8)	✓
	Amount of condensation in the insulation layer?	✓



Construction unproblematic from the moisture point of view!